

QIAasymphony[®] SP Protocol Sheet

Cellfree500_V5_DSP protocol

Version management

This document is the QIAasymphony Cellfree500_V5_DSP Protocol Sheet, Version 1, R1.

General information

For in vitro diagnostic use.

Kit	QIAasymphony DSP Virus/Pathogen Midi Kit
Sample material*	Plasma, serum, and CSF
Protocol name	Cellfree500_V5_DSP
Default Assay Control Set	ACS_Cellfree500_V5_DSP_default_IC
Editable	Eluate volume: 60 μ l, 85 μ l, 110 μ l
Required software version	Version 4.0

* For additional information see "Preparation of sample material" and "Limitations", page 6.

February 2014



Sample & Assay Technologies

“Sample” drawer

Sample type	Plasma, serum, and CSF
Sample volume	Depends on type of sample tube used; for more information see www.qiagen.com/goto/dsphandbooks
Primary sample tubes	See www.qiagen.com/goto/dsphandbooks for more information
Secondary sample tubes	See www.qiagen.com/goto/dsphandbooks for more information
Inserts	Depends on type of sample tube used; for more information see www.qiagen.com/goto/dsphandbooks
Other	Carrier RNA–Buffer AVE mix required; use of internal control is optional

“Reagents and Consumables” drawer

Position A1 and/or A2	Reagent cartridge (RC)
Position B1	n/a
Tip rack holder 1–17	Disposable filter-tips, 200 μ l
Tip rack holder 1–17	Disposable filter-tips, 1500 μ l
Unit box holder 1–4	Unit boxes containing sample prep cartridges
Unit box holder 1–4	Unit boxes containing 8-Rod Covers

n/a = not applicable.

“Waste” drawer

Unit box holder 1–4	Empty unit boxes
Waste bag holder	Waste bag
Liquid waste bottle holder	Liquid waste bottle

“Eluate” drawer

Elution rack (we recommend using slot 1, cooling position)

See www.qiagen.com/goto/dsphandbooks for more information

Required plasticware

	One batch, 24 samples*	Two batches, 48 samples*	Three batches, 72 samples*	Four batches, 96 samples*
Disposable filter-tips, 200 μ l ^{††}	32	56	80	104
Disposable filter-tips, 1500 μ l ^{††}	109	198	297	386
Sample prep cartridges [§]	21	42	63	84
8-Rod Covers [¶]	3	6	9	12

* Use of more than one internal control per batch and performing more than one inventory scan requires additional disposable filter-tips. Use of less than 24 samples per batch decreases the number of disposable filter-tips required per run.

[†] There are 32 filter-tips/tip rack.

^{††} Number of required filter-tips includes filter-tips for 1 inventory scan per reagent cartridge.

[§] There are 28 sample prep cartridges/unit box.

[¶] There are twelve 8-Rod Covers/unit box.

Note: Numbers of filter-tips given may differ from the numbers displayed in the touchscreen depending on settings, for example, number of internal controls used per batch.

Selected elution volume

Selected elution volume (μl)*	Initial elution volume (μl)†
60	90
85	115
110	140

* The elution volume selected in the touchscreen. This is the minimum accessible volume of eluate in the final elution tube.

† The initial volume of elution solution required to ensure that the actual volume of eluate is the same as the selected volume.

Preparation of internal control–carrier RNA (CARRIER)–Buffer AVE (AVE) mixture

Selected elution volume (μl)	Volume stock carrier RNA (CARRIER) (μl)	Volume internal control (μl)*	Volume Buffer AVE (AVE) (μl)	Final volume per sample (μl)
60	5	9	106	120
85	5	11.5	103.5	120
110	5	14	101	120

* The calculation of the amount of internal control is based on the initial elution volumes. Additional void volume depends on the type of sample tube used; see www.qiagen.com/goto/dsphandbooks for more information.

Note: The values displayed in the table are for preparation of internal control–carrier RNA (CARRIER) mixture for a downstream assay that requires 0.1 μl internal control/ μl eluate.

Tubes containing internal control–carrier RNA (CARRIER)–Buffer AVE (AVE) mixture are placed in a tube carrier. The tube carrier containing the internal control–carrier RNA (CARRIER)–Buffer AVE (AVE) mixture(s) must be placed in slot A of the sample drawer.

Depending on the number of samples to be processed, we recommend using 2 ml tubes (Sarstedt, cat. no. 72.693 or 72.694) or 14 ml 17 x 100 mm polystyrene, round-bottom tubes (Becton Dickinson, cat. no. 352051) for diluting the internal control, as described in the table on page 5. The volume can be split into 2 or more tubes.

Calculating the volume of internal control mixture

Tube type	Name on QIASymphony touchscreen	Calculation of internal control-carrier RNA (CARRIER)-Buffer AVE (AVE) mixture volume per tube
Microtube 2 ml with cap; microtube 2 ml, PP, SKIRTED, (Sarstedt, cat. No. 72.694)	SAR#72.694 T2.0 ScrewSkirt	$(n \times 120 \mu\text{l}) + 360 \mu\text{l}^*$
Microtube 2 ml with cap; microtube 2 ml, PP, NON-SKIRTED, (Sarstedt, cat. No. 72.693)	SAR#72.693 T2.0 Screw	$(n \times 120 \mu\text{l}) + 360 \mu\text{l}^*$
Tube 14 ml, 17 x 100 mm polystyrene round-bottom (Becton Dickinson, cat. no. 352051)	BD#352051 FalconPP 17x100	$(n \times 120 \mu\text{l}) + 600 \mu\text{l}^\dagger$

* Use this equation to calculate the required volume of internal control mixture (n = number of samples; $120 \mu\text{l}$ = volume of internal control-carrier RNA (CARRIER)-Buffer AVE (AVE) mixture; $360 \mu\text{l}$ = void volume required per tube). For example, for 12 samples ($n = 12$): $(12 \times 120 \mu\text{l}) + 360 \mu\text{l} = 1800 \mu\text{l}$. Do not fill the tube with more than 1.9 ml (i.e., a maximum of 12 samples per tube). If more than 12 samples will be processed, use additional tubes, ensuring that the void volume is added per tube.

† Use this equation to calculate the required volume of internal control-carrier RNA (CARRIER)-Buffer AVE (AVE) mixture (n = number of samples; $120 \mu\text{l}$ = volume of internal control-carrier RNA (CARRIER)-Buffer AVE (AVE) mixture; $600 \mu\text{l}$ = void volume required per tube). For example, for 96 samples ($n = 96$): $(96 \times 120 \mu\text{l}) + 600 \mu\text{l} = 12120 \mu\text{l}$.

See www.qiagen.com/goto/dsphandbooks for required inserts.

Preparation of sample material

When working with chemicals, always wear a suitable lab coat, disposable gloves, and protective goggles. For more information, consult the appropriate safety data sheets (SDSs), available from the product supplier.

Plasma, serum, and CSF samples

The purification procedure is optimized for use with plasma, serum, or CSF samples. Blood samples treated with EDTA or citrate as anticoagulant can be used for plasma preparation. Samples can be either fresh or frozen, provided that they have not been frozen and thawed more than once. After collection and centrifugation, plasma, serum, or CSF can be stored at 2–8°C for up to 6 hours. For longer storage, we recommend freezing aliquots at –20°C or –80°C. Frozen plasma or serum must not be thawed more than once. Repeated freeze–thawing leads to denaturation and precipitation of proteins, resulting in a potential reduction in viral titers and, therefore, reduced yields of viral nucleic acids. If cryoprecipitates are visible in the samples, centrifuge at 6800 x g for 3 minutes, transfer the supernatants to fresh tubes without disturbing the pellets, and start the purification procedure immediately. Centrifugation at low g-forces does not reduce viral titers.

Limitations

Blood samples treated with serum clot activator may cause reduced yields of viral nucleic acids. Do not use Greiner Bio-One® VACUETTE® Blood Collection Tubes containing Z Serum Clot Activator.

For up-to-date licensing information and product-specific disclaimers, see the respective QIAGEN kit handbook or user manual. QIAGEN kit handbooks and user manuals are available at www.qiagen.com or can be requested from QIAGEN Technical Services or your local distributor.

Trademarks: QIAGEN®, QIASymphony® (QIAGEN Group); BD™ (Becton Dickinson and Company); Falcon® (Corning, Inc.); Bio-One®, VACUETTE® (Greiner Bio-One GmbH); Sarstedt® (Sarstedt AG and Co.). Registered names, trademarks, etc. used in this document, even when not specifically marked as such, are not to be considered unprotected by law.

Feb-14 HB-0301-S34-001 © 2012–2014 QIAGEN, all rights reserved.

www.qiagen.com

Australia = 1-800-243-800

Austria = 0800-281011

Belgium = 0800-79612

Brazil = 0800-557779

Canada = 800-572-9613

China = 800-988-0325

Denmark = 80-885945

Finland = 0800-914416

France = 01-60-920-930

Germany = 02103-29-12000

Hong Kong = 800 933 965

India = 1-800-102-4114

Ireland = 1800 555 049

Italy = 800-787990

Japan = 03-6890-7300

Korea (South) = 1544 7145

Luxembourg = 8002 2076

Malaysia = 603-7981-5510

Mexico = 01-800-7742-436

The Netherlands = 0800 0229592

Norway = 800-18859

Singapore = 1800-742-4368

Spain = 91-630-7050

Sweden = 020-790282

Switzerland = 055-254-22-11

Taiwan = 0080-665-1947

UK = 0808-234-3665

USA = 800-426-8157



Sample & Assay Technologies